

Nols Muller


DC drives Upgrade Kits DCV700/DCS500/DCS600 → DCS800



Power and productivity for a better world™

© ABB Group May 13, 2013 | Slide 1

DCS800-R Upgrade Kits Upgrade solutions for DCS500 / DCS800 drives



- Upgrade of DCS500 / DCS500B / DCS600 to DCS800
- Available for modules
 - DCS500 / DCV700 (based on SDCS-CON-1)
 - 680A ... 5150A
 - Sizes: C2b, C3, C4
 - DCS500B / DCS600 (based on SDCS-CON-2)
 - 900A ... 5200A
 - Sizes: A5, A6, A7
- Content of an Upgrade Kit (Standard)
 - Control board SDCS-CON-4 with SDCS-DSL-4
 - Electronics power supply board SDCS-POW-4
 - Measuring board SDCS-PIN-51 (only when needed)
 - DCS800 Control Panel
 - Cables
 - Mechanical parts for assembling



DCS800-R Upgrade Kits Availability overview for DCS500/DCV700

Converter type	Dimensions H x W x D [mm]	Weight [kg]	Clearances top/bottom/side [mm]	Construct. type	Power loss at 500V P _v [kW]	Fan connection	Semiconductor Fuses
DCS50x-0025-y1 DCS50x-0050-y1 DCS50x-0050-61 DCS50x-0075-y1 DCS50x-0100-y1	420x273x195 420x273x195 420x273x195 420x273x195 420x273x195 469x273x228	7.1 7.2 7.6 7.6 11.5	150x100x5 150x100x5 150x100x5 150x100x5 150x100x5 250x150x5	C1 C1 C1 C1 C1	< 0.2 < 0.2 - < 0.3 < 0.5	230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph	extem extem extem extem extem
DCS50x-0110-61 DCS50x-0140-y1	469x273x228 469x273x228	11.5 11.5	250x150x5 250x150x5	C1 C1	- < 0.6	230 V/1 ph 230 V/1 ph	extern extern
DCS50x-0200-y1 DCS50x-0250-y1 DCS50x-0270-61 DCS50x-0350-y1 DCS50x-0450-y1 DCS50x-0520-y1 DCS50x-0700-y1	505x273x361 505x273x361 505x273x361 505x273x361 505x273x361 505x273x361 505x273x361 652x273x384	22.3 22.3 22.8 22.8 28.9 28.9 28.9 57	250x150x5 250x150x5 250x150x5 250x150x5 250x150x10 250x150x10 250x150x10	888888	< 0.8 < 1.0 - < 1.3 < 1.5 < 1.8 < 2.5	230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph	extern extern extern extern extern extern extern
DCS50x-0900-y1 DCS50x-1200-y1 DCS50x-1500-y1 DCS50x-2000-y1	1493x548x447 1493x548x447 1493x548x447 1493x548x447 1493x548x447	150 150 150 150	300x100x20 300x100x20 300x100x20 300x100x20 300x100x20	8 8 8 8 8 8	< 4.8 < 6.2 < 6.3 < 8.2	400/690 V/3 ph 400/690 V/3 ph 400/690 V/3 ph 400/690 V/3 ph	intem intem intem intem
DCS50x-2050-y1 DCS50x-2500-y1 DCS50x-2650-y1 DCS50x-3200-y1 DCS50x-3300-y1 DCS50x-4000-y1 DCS50x-4750-y1 DCS50x-5150-y1	2330x820x624 2330x820x624 2330x820x624 2330x820x624 2330x820x624 2330x820x624 2330x820x624 2330x820x624 2330x820x624	350 350 350 350 350 350 350 350 350	to be installed in cubicle	C4 C4 C4 C4 C4 C4 C4 C4 C4 C4 C4 C4 C4 C	- < 12 - < 15 < 16 - < 20	400/690 V/3 ph 400/690 V/3 ph 400/690 V/3 ph 400/690 V/3 ph 400/690 V/3 ph 400/690 V/3 ph 400/690 V/3 ph	intem intem intem intem intem intem intern intern

DCS800-R Upgrade kits are only available for yellow highlighted converter types



DCS800-R Upgrade Kits Availability overview for DCS500B/DCS600

Converter type	Dimensions H x W x D [mm]	Weight [kg]	Clearances top/bottom/side [mm]	Construct. type	Power loss at 500V P _v [kW]	Fan connection	Semiconductor Fuses
DCS50xB0025-y1 DCS50xB0050-y1 DCS50xB0050-61 DCS50xB0075-y1 DCS50xB0100-y1 DCS50xB0110-61	420x273x195 420x273x195 420x273x195 420x273x195 420x273x195 469x273x228 469x273x228	7.1 7.2 7.6 7.6 11.5 11.5	150x100x5 150x100x5 150x100x5 150x100x5 250x150x5 250x150x5	C1a C1a C1a C1a C1b C1b C1b	< 0.2 < 0.2 - < 0.3 < 0.5	230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph	external external external external external external
DCS50xB0140-y1 DCS50xB0200-y1 DCS50xB0250-y1 DCS50xB0270-61 DCS50xB0350-y1 DCS50xB0450-y1 DCS50xB0520-y1 DCS50xB0680-y1	469x273x228 505x273x361 505x273x361 505x273x361 505x273x361 505x273x361 505x273x361 505x273x361 652x273x384	11.5 22.3 22.3 22.8 22.8 28.9 28.9 28.9 42	250x150x5 250x150x5 250x150x5 250x150x5 250x150x5 250x150x5 250x150x10 250x150x10 250x150x10	C1b C2a C2a C2a C2a C2a C2a C2a C2a	< 0.6 < 0.8 < 1.0 - < 1.3 < 1.5 < 1.8 < 1.6	230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1 ph	external external external external external external external external
DCS50xB0680-y1 DCS50xB0820-y1 DCS50xB1000-y1	652x273x384 652x273x384 652x273x384 1050x510x410	42 42 42 110	250x150x10 250x150x10 250x150x10 300x100x20	C2b C2b C2b A5	< 1.6 < 2.0 < 2.5	230 V/1 ph 230 V/1 ph 230 V/1 ph 230 V/1-ph	external external external
DCS50xB1203-y1 DCS50xB1503-y1 DCS50xB2003-y1	1050x510x410 1050x510x410 1050x510x410	110 110 110	300x100x20 300x100x20 300x100x20	A5 A5 A5	< 5.2 < 5.5 < 6.6	230 V/1-ph 230 V/1-ph 230 V/1-ph 230 V/1-ph	internal internal internal
DCS50xB1903-81 DCS50xB2053-y1 DCS50xB2503-y1 DCS50xB3003-y1	1750x460x410 1750x460x410 1750x460x410 1750x460x410	180 180 180 180	③ x0x50 ③ x0x50 ③ x0x50 ③ x0x50 ③ x0x50	A6 A6 A6 A6	- < 7.9 < 9.3 < 11.9	400500 V/3-ph at y = 4, 5, 8 500690 V/3-ph at y = 6, 7	internal
DCS50xB2053-y1L① DCS50xB2603-y1L① DCS50xB3203-y1L① DCS50xB3303-y1L① DCS50xB4003-y1L③ DCS50xB4003-y1L③ DCS50xB4803-y1L③	1750x770x570 1750x770x570 1750x770x570 1750x770x570 1750x770x570 1750x770x570	315 315 315 315 315 315 315 315	to be installed in cubicle	A7 A7 A7 A7 A7 A7 A7 A7	- - < 15 < 16 - < 20	400/690 V/3-ph 400/690 V/3-ph 400/690 V/3-ph 400/690 V/3-ph 400/690 V/3-ph 400/690 V/3-ph	internal

DCS800-R Upgrade kits are only available for yellow highlighted converter types



DCS800-R Upgrade Kits Requirements and Design conditions for Upgrades

Requirements

- Converter modules DCS500, DCS500B (except Unitrol), DCS600
- DC Voltage 400VAC up to 1000 VAC
- Nominal current 680A up to 5200A
- Sufficient physical condition of the existing module

Design conditions

- Max. 24VDC control voltage for SDCS-CON-4 instead of 48VDC
- Upgrades DCS600 -> DCS800 require SDCS-COM-8x board for fiber optic connections
- Old field exciters have to be exchanged due to DCSLink Communication.
- Line chokes can be reused if field settings remain unchanged
- I/O extension board SDCS-IOE-1 has to be exchanged by RDIO-01 and RAIO-01
- New commissioning tool DriveWindow 2.2 or higher is needed



DCS800-R Upgrade Kits Supported and not supported parts

Supported parts

- I/O board SDCS-IOB-2x
- I/O board SDCS-IOB-3,
- control panel CDP 312 xx via SDCS-COM-81 or SDCS-COM-82 and
- Nxxx fieldbus adapter used with DCS 500B or DCS 600 via SDCS-COM-82

Not supported parts


- all old field exciters for DCS 500, DCS 500B and DCS 600,
- DCS-IOE-1
- control panels CDP 310 and CDP 311
- Nxxx fieldbus adapter used with DCS 500
- APC1 used for DCV 700
- Reuse of APC2 requires modifications in the control logic and additional hardware
- All old tools like DDCTool, CMTTool, DriveWindow 1.x and DriveWindow 2.1

DCS800-R Upgrade Kits Conditions caused by the application

- In case of an additional application three scenarios are possible
 - Application program located in the APC1 or APC2 of a DCV 700.
 - APC1: No interface available
 - APC2: Optical connection board YPQ112 is to add between APC2 and SDCS-COM-81 and control logic is to modify
 - The application program is as function blocks in the DCS 500 or DCS 500B. → DriveAP Programmimg or CoDeSys Programming
 - The application program is located in the AMC board of a DCS 600 see APPLIC NAME (4.03) → CoDeSys Programming
- Master-follower configurations
 - Master-follower via SDCS-COM-8 should be used for upgrading a DCS 600. The fiber optic cable can be reused.
 - Master-follower via DCSLink should be used for upgrading a DCS 500 or DCS 500B.
- Hard-Parallel configuration
 - Additional engineering is needed. Please contact your local ABB .



DCS800-R Upgrade Kits Upgrade size A5 to D5



Article Codes

DCS800-R00-9305

DCS800-R00-9306 (with field exciter)

Included parts


- SDCS-POW-4
- FEX-425-Int (only DCS800-R00-9306)
- electronic tray
- SDCS-CON-4 with SDCS-DSL-4
- covers
- DCS800 Control Panel
- SDCS-PIN-51
- all boards are coated

Affected modules: Converter type DCS 500B DCS50xB0903-y1 DCS50xB1203-y1 DCS50xB1503-y1 DCS50xB2003-y1

Converter type DCS 600 DCS60x-0903-y1 DCS60x-1203-y1 DCS60x-1503-y1 DCS60x-2003-y1



DCS800-R Upgrade Kits Upgrade size A6/A7 to D6/D7



Article Code

DCS800-R00-9405

Included parts


- SDCS-POW-4
- electronic tray
- SDCS-CON-4 with SDCS-DSL-4
- SDCS-PIN-51
- covers
- DCS800 Control Panel
- all boards are coated

Affected modules:

Converter type DCS 500B **Converter type DCS 600** DCS50xB1903-y1 DCS60x-1903-y1 DCS50xB2053-y1 DCS60x-2053-y1 DCS60x-2503-y1 DCS50xB2503-y1 DCS60x-3003-y1 DCS50xB3003-y1 DCS50xB2053-y1 DCS60x-2053-y1 DCS60x-2603-y1 DCS50xB2603-y1 DCS60x-3203-y1 DCS50xB3203-y1 DCS50xB3303-y1 DCS60x-3303-y1 DCS50xB4003-y1 DCS60x-4003-y1 DCS60x-4803-y1 DCS50xB4803-y1 DCS50x-5203-y1 DCS50xB5203-y1



DCS800-R Upgrade Kits Upgrade size C2b to D5



Article Code

DCS800-R00-9005

Included parts


- SDCS-POW-4
- electronic tray
- SDCS-CON-4 with SDCS-DSL-4
- covers
- DCS800 Control Panel
- <u>all boards are coated</u>

Affected modules:

Converter type DCS 500B DCS50x-0680-y1 DCS50x-0820-y1 DCS50x-1000-y1 Converter type DCS 600 DCS60x-0680-y1 DCS60x-0820-y1 DCS60x-1000-y1



DCS800-R Upgrade Kits Upgrade size C3 to D6



Article Code

DCS800-R00-9205

Included parts

- SDCS-POW-4
- electronic tray
- SDCS-CON-4 with SDCS-DSL-4
- SDCS-PIN-51
- covers
- DCS800 Control Panel
- all boards are coated


Affected modules:

Converter type DCS 500B DCS50xB0900-y1 DCS50xB1200-y1 DCS50xB1500-y1 DCS50xB2000-y1

Converter type DCS 600 DCS60x-0900-y1 DCS60x-1200-y1 DCS60x-1500-y1 DCS60x-2000-y1



DCS800-R Upgrade Kits Upgrade size C4 to D7



Article Code

DCS800-R00-9105

Included parts


- SDCS-POW-4
- electronic tray
- SDCS-CON-4 with SDCS-DSL-4
- SDCS-PIN-51
- covers
- DCS800 Control Panel
- all boards are coated

Affected modules:

Converter type DCS 500B DCS50xB2050-y1 DCS50xB2500-y1 DCS50xB2650-y1 DCS50xB3200-y1 DCS50xB3300-y1 DCS50xB4000-y1 DCS50xB4750-y1 DCS50xB5150-y1 Converter type DCS 600 DCS60x-2050-y1 DCS60x-2500-y1 DCS60x-2650-y1 DCS60x-3200-y1 DCS60x-3300-y1 DCS60x-4000-y1 DCS60x-4750-y1 DCS50x-5150-y1




DCS800-R Upgrade Kits Overview Parts Upgrade Kit






DCS800-R Upgrade Kits DCV700 System Structure



DCS800-R Upgrade Kits How to connect existing control system to SDCS-CON-4 (1/3)

Extension of APC2 controller with a DDCS interface adapter.




Please note:

Installation of the YPQ112B interface adapter requires small modifications in the APC control program. Availability of the right software tools and programming skills for APC controller are to ensure.



DCS800-R Upgrade Kits How to connect existing control system to SDCS-CON-4 (2/3)

Removal of APC2 and direct connection to the overriding system via AF100 (MB90)




Please note:

Installation of the CI810B communication interface requires small modifications in the overriding control system e.g. AC450. Furthermore the removal of the APC controller requires adaption of the existing APC software program either into the overriding system or into the drive via DriveAP or CoDeSys. Availability of the right software tools and programming skills are to ensure.



DCS800-R Upgrade Kits How to connect existing control system to SDCS-CON-4 (3/3)

Removal of APC2 and direct connection to the overriding system via MFB (MasterFieldbus)



Please note:

Installation of the PE1354B fieldbus converter requires small modifications in the overriding control system e.g. MP200. Furthermore the removal of the APC controller requires adaption of the existing APC software program either into the overriding system or into the drive via DriveAP or CoDeSys. Availability of the right software tools and programming skills are to ensure.



DCS800-R Upgrade Kits Upgrade Kits - Additional Information

- Manual with detailed information
 - For further information regarding hardware, assembling and commissioning see Manual 3ADW00256R0101
- Parameter settings
 - After upgrading parameters have to be adjusted due to different parameter groups in DCS500/DCS600 and DCS800.
 - For parameter comparison see document 3ADW000405R0201
- Sales Chanel





Power and productivity for a better world[™]

